one communications – Yealink T46G phoneset quick reference

Updated: Dec 2018

Features	Instructions
Dialing out	Lift the handset + (Phone no.) + [#] Note: No need to dial [9] before the phone no.
Intercom dialing	Lift the handset + (Extension no.) + [#]
Intercom dialing (using "busy lamp")	Lift the handset + [Busy lamp for that ext.]
Last number redial	Lift the handset + [↻] + [↻]
Speed dialing	To dial: Lift the handset + [*] + [*] + (code no. 00 - 99) + [#]
Volume adjustment	Ringtone: (- ━━▮━━ +) to decrease or increase Voice: Lift the handset + (- ━━▮━━ +) to decrease or to increase
Holding call	To hold: (Call connected) + [☎] (T46G) To retrieve: (Call held) + [☎] (T46G)
Call waiting	To answer: (Busy tone sounds) + [Flashing line button] To set: [*] [1] [7] + [#] To cancel: [#] [1] [7] + [#]
All call forwarding	To set: [*] [0] [5] + (phone / extension no.) + [#] To cancel: [#] [0] [5] + [#]
All call forwarding (remote setting)	Use any other phone: (Dial 2205 1111 or 2562 0111 or 2204 1111) + (Your phone no.) + [#] + (Voicemail passcode) + [#] + [3]
Busy call forwarding	To set: [*] [2] [5] + (phone / extension no.) + [#] To cancel: [#] [2] [5] + [#]
No answer call forwarding	To set: [*] [3] [5] + (phone / extension no.) + [#] To cancel: [#] [3] [5] + [#]
Do not disturb (DND)	To set: [*] [0] [1] + [#] To cancel: [#] [0] [1] + [#]
Call transfer - Blind transfer	(Call connected) + [↙] + (Extension no.) + [↙] (T46G) Or (Call connected) + dsskey Hard Key1 (Transfer) + (Extension no.) + dsskey Hard Key1 (Transfer) (T46G)
Call transfer - Consultation transfer	(Call connected) + [↙] + (Extension no.) + [#] + Wait for answer + [↙] Or (Call connected) + dsskey Hard Key1 (Transfer) + (Extension no.) + [#] + Wait for answer + dsskey Hard Key1 (Transfer) + Hang up (T46G)

Conferencing call	(Call connected) + dsskey Hard Key3 (Conference) + (Phone no.) + [#] + wait for answer + dsskey Hard Key3 (Conference) (T46G)
Call park and retrieve	Call park: (Call connected) + [another line key] + [*] [8] [4] + [#] + [#] + Hang up Call retrieve: Lift the handset + [#] [8] [4] + [#] + (Self extension no.) + [#]
Group pick-up	Lift the handset + [*] [1] [1] + [#]
Call pick-up	By feature access code, applicable to ALL extensions: Lift the handset + [*] [2] [1] + (Ringing extension no.) + [#] By "busy" lamp field, applicable to preset extensions: Lift the handset + [Busy lamp for that ext.]
Paging	Lift the handset + (Group Paging Extension no.) + [#]
Boss and secretary	Sec makes outgoing call using Boss line: Lift the handset + [Boss line key] + (Phone/ extension no.) + [#] Sec picks up incoming call on Boss line: Lift the handset + [Boss line key]
Listen to voicemail	✉ + Lift the handset OR [*] [9] [0] + [Dial] + Lift the handset
Listen to voicemail (outside office)	Using other phone: (Dial 2205 1111 or 2562 0111 or 2204 1111) + (Your phone no.) + [#] + (Your voicemail passcode) + [#] + [1]
Phone book	dsskey Hard Key1 (Phone Book) + Choose [All Contact] or [Company] or [Personal]
Call logs	dsskey Hard Key2 (Call log) + Choose [All Call log] or [Placed Call log] or [Missed Call log] or [Received Call log]
IDD & chargeable call password	To lock: [*] [0] [4] + [#] + (System will prompt to enter password) + (Password) + [#] To unlock: [#] [0] [4] + [#] + (System will prompt to enter password) + (Password) + [#]
Call pull (for fixed mobile convergence)	From mobile to office phone: [*] [8] [8] + [#] From office to mobile phone: (Dial 2513 1111) + [*] [8] [8]
Menu	To view information menu: [Menu]

*** Boss / Sec plan phone set model: Yealink T46G**