

## **ONE** communications (network version - cordless user) - quick reference

Updated: Dec 2013

|                                      | Updated: Dec 2013   |
|--------------------------------------|---|
| Description                          | Operation   |
| Dialing out                          | (Phone no.) + [ TALK ]<br>Note: <b>NO</b> need to dial [ 9 ] before the phone no.                           |
| Intercom dialing                     | (Lift up handset) + ( Extension no. ) + [ TALK ]  |
| System hold                          | To hold: (Speaking) + press [ HOLD ] key<br>To retrieve: Press the [ HOLD ] key                             |
| Volume adjustment                    | To increase volume: [MENU][Up]key<br>To decrease volume: [MENU][Down]key                                    |
| Last number redial                   | Press [ REDIAL ] key  |
| Speed dialing                        | To press and hold: 1 ~ 9 + [ TALK ]   |
| Call transfer                        | Press [ MENU ] > [ Blind Transfer ] key   |
| Call transfer with consultation      | Press [ MENU ] > [ Transfer ] key   |
| 3-way conference                     | Press [ MENU ] > [ Conference ] key   |
| All call forwarding                  | To set: [*][0][5]+ (Phone/Extension no.) + [TALK]<br>To cancel: [#][0][5]+ [TALK]                           |
| Busy call forwarding                 | To set: [*][2][5] + (Phone/Extension no.) + [TALK]<br>To cancel: [#][2][5] + [TALK]                         |
| No answer call forwarding            | To set: [*][3][5] + (Phone/Extension no.) + [TALK]<br>To cancel: [#][3][5] + [TALK]                         |
| Call waiting                         | When busy tone sounds and press [ SWITCH ] key<br>To set: [*][1][7]+[TALK]<br>To cancel: [#][1][7]+[TALK]   |
| Group pick-up                        | [*][1][1]+[TALK]  |
| Call pick-up                         | Press [*][2][1]+ (Ringing extension no.) + [TALK]   |
| Do not disturb (DND)                 | To set: [DND], press [ * ] [ 0 ] [ 1 ] + [ TALK ]<br>To cancel: [DND], press [ # ] [ 0 ] [ 1 ] + [ TALK ]   |
| Listen to voicemail                  | Press [*][9][0]+[TALK]  |
| Listen to voicemail (outside office) | From other phones: (dial 2205 1111 or 2562 0111) + (Your phone no.) + [#] + (Your voicemail passcode) + [#] |
| IDD & chargeable call password       | To lock: [*][0][4]+[TALK], system will prompt to enter password,<br>(password) + [#]                        |
|                                      | To unlock: [#][0][4]+[TALK], system will prompt to enter password,<br>(password) + [#]                      |





| Phone book   | Press [ MENU ] -> [ Phonebook ] key  |
|--|--|
| Call log   | Missed Call: [ CID ] -> [ MENU ] [ Down ] call list without tick<br>Incoming Call: [ CID ] -> [ MENU ] [ Down ] call list with tick<br>Outgoing Call: [ REDIAL ] |
| Cardless plan phone act model: Denegania KX TCD500, KX TDA50 |  |

Cordless plan phone set model: Panasonic KX-TGP500, KX-TPA50

Service hotline number: 1833 111

one communications help link: http://www.pccwone.com/chi/new\_version\_help.html Voice mail box and email reminder: customer is recommended to clean up voice mail box and email regularly.



a PCCW Group member