

















## one communications (Network version – Cordless User) Panasonic TGP600 quick guide

Description	Operation
<b>Dialing out</b>	(Phone no.) +  key Note: <b>NO</b> need to dial [9] before the phone no.
<b>Intercom dialing</b>	(Lift up handset) + (Extension no.) +  鍵
<b>System hold</b>	To hold: (speaking) + press  key To retrieve: Press the [CANCEL] key
<b>Volume adjustment</b>	To increase ringer volume: UP (▲) key To decrease ringer volume: DOWN (▼) key To increase receiver volume: UP (▲) key To decrease receiver volume: DOWN (▼) key
<b>Last number redial</b>	Press [FUNC] key + choose [1:Redial] + [OK] key
<b>Speed dialing</b>	Dial [**00] ~ [**99]
<b>Call transfer / Call transfer with consultation</b>	1. (speaking) +  key 2. Dial the party you want to transfer to + [CALL] key 3. Wait until the other party answers to announce the transfer +  key
<b>Blind transfer</b>	1. (speaking) + [BLIND] key 2. Dial the party you want to transfer to + [CALL] key
<b>3-way conference</b>	1. (speaking) + Press [FUNC] key + choose [3:Conference] + [OK] key 2. Dial the party you want to add the conversation + [CALL] key 3. Press  key
<b>All call forwarding</b>	To set: Press [FUNC] key + choose [2:FWD/DND] + [OK] + choose [Fwd(All)] + [On] + [OK] key To cancel: Press [FUNC] key + choose [2:FWD/DND] + [OK] + choose [Fwd(All)] + [Off] + [OK] key
<b>Busy call forwarding</b>	To set: Press [FUNC] key + choose [2:FWD/DND] + [OK] + choose [Fwd(Busy)] + [On] + [OK] key To cancel: Press [FUNC] key + choose [2:FWD/DND] + [OK] + choose [Fwd(Busy)] + [Off] + [OK] key
<b>No answer call forwarding</b>	To set: Press [FUNC] key + choose [2:FWD/DND] + [OK] + choose [Fwd(NA)] + [On] + [OK] key To cancel: Press [FUNC] key + choose [2:FWD/DND] + [OK] + choose [Fwd(NA)] + [Off] + [OK] key
<b>Call waiting</b>	To set: [*][1][7] +  key To cancel: [#][1][7] +  key
<b>Group pick-up</b>	Press [*][1][1] +  key
<b>Call pick-up</b>	Press [*][2][1] + (ringing extension no.) +  key
<b>Do not disturb (DND)</b>	To set: Press [FUNC] key + choose [2:FWD/DND] + [OK] + choose [DND] + [On] + [OK] key To cancel: Press [FUNC] key + choose 2:FWD/DND] + [OK] + choose [DND] + [Off] + [OK] key
<b>Listen to voicemail (outside office)</b>	From other phones: (dial 22051111) + (your phone no.) + (your voicemail passcode)

類型	操作
IDD & chargeable call password	To lock: [ * ][ 0 ][ 4 ] +  key, system will prompt to enter password, (password) + [ # ] To unlock: [ # ][ 0 ][ 4 ] +  key, system will prompt to enter password, (password) + [ # ]
Phone book	Press  key
Call log	Outgoing Call Log: Press  key Missed Call Log and Incoming Call Log: Press  key + choose  + [OK] key

Cordless plan phone set model: Panasonic TGP600 DECT Phone

Service hotline number : **1833 111**

**one communications** 支援鏈接 : [http://www.pccwone.com/chi/new\\_version\\_help.html](http://www.pccwone.com/chi/new_version_help.html)

Voice mail box and email reminder: customer is recommended to clean up voice mail box and email regularly.